



1/4"
pilot with small drill bit
use nylon nut on existing stud

3/8"
pilot with small drill bit
use existing liner push tab