




Installing LATCH Child Seats

Lower LATCH anchor positions are provided in the second-row outboard seating positions and are located between the seat's back rest and rear cushion. The exact location of each anchor is identified by a child safety seat identification button, illustrated below. The button is located on the seat back, directly above its associated anchor.



Install LATCH seats in the outboard seating positions only. Use only a seat belt retained seat in the center position.



To install a LATCH retained child safety seat, slide the safety seat latches onto the anchor bars until they click into place. Carefully read and follow the instructions provided by the child safety seat manufacturer.



Once installed, test the security of the installation before seating a child. Attempt to twist the child safety seat from side to side and try to pull it away from the seat, then check that the anchors are still securely in place.

Attaching Upper Tether Straps

If an upper tether strap is provided, attach its hook to the anchor point located on the back of the rear seats. Always position single-strap tethers so that it runs over the center of the Model S head support. Tighten dual-strap tethers to run on each side of the head support. Tighten according to the child safety seat manufacturer's instructions.

Note: To prevent single-strap tethers from moving from side to side, the top of the head support deforms.

