

| Job Number | Description Of Work | | | | |
|---|--|------|----------|---|---|
| 1 | <p>Concern: Replace Bolts In Steering Rack Housing</p> <p>Corrections: Replace Bolts In Steering Rack Housing And Apply Wax Sealant (LHD Dual Motor)</p> <p>Replaced bolts in steering rack housing, per factory bulletin.</p> <p>Parts Replaced or Added</p> <table> <tr> <th>Part</th><th>Quantity</th></tr> <tr> <td>STEEL BOLTS FOR BOSCH STEERING GEAR (Set of 5) (1460671-00-A)</td><td>1</td></tr> </table> <p>Pay Type: Warranty</p> | Part | Quantity | STEEL BOLTS FOR BOSCH STEERING GEAR (Set of 5) (1460671-00-A) | 1 |
| Part | Quantity | | | | |
| STEEL BOLTS FOR BOSCH STEERING GEAR (Set of 5) (1460671-00-A) | 1 | | | | |
| 2 | <p>Concern: Customer: Vehicle has no power steering. Towed in to service center.</p> <p>Corrections: Steering Rack and Lower Column General Diagnosis</p> <p>Upon diagnosis, determined intermediate steering column needs replacement.</p> <p>Corrections: Shaft - Steering Column - Intermediate Lower (Dual Motor)</p> <p>Replaced intermediate steering shaft between steering column and rack, torqued to specification. Verified alerts no longer present. Test drove vehicle and confirmed steering to be functioning as designed following repairs.</p> <p>Parts Replaced or Added</p> <table> <tr> <th>Part</th><th>Quantity</th></tr> <tr> <td>I-SHAFT STEERING LINK - NON ISOLATOR - LOWER (1030622-00-A)</td><td>1</td></tr> </table> <p>Pay Type: Warranty</p> | Part | Quantity | I-SHAFT STEERING LINK - NON ISOLATOR - LOWER (1030622-00-A) | 1 |
| Part | Quantity | | | | |
| I-SHAFT STEERING LINK - NON ISOLATOR - LOWER (1030622-00-A) | 1 | | | | |